

SECTION DETAIL OF RISER CONNECTION TO TANK OPENING NECK

NOTES:

TANK IS PROVIDED WITH HEAVY DUTY ACCESS LID AND ADAPTOR RING ATTACHED TO TANK FOR SHIPPING PURPOSES ONLY. RISERS CAN BE CONNECTED TO THE ADAPTOR RING OR CONNECTED DIRECTLY TO THE TANK IF THE CUT IS MIDPOINT BETWEEN THE RIBS. TANKS ARE DESIGNED FOR A MAXIMUM COVER DEPTH OF 4 FT.



ULTRARIB RISER JOINT TO BOBBLE TANKS

BELOW GROUND OR ABOVE GROUND APPLICATIONS.
MEDIUM DENSITY POLYETHYLENE

DATE: APRIL 2019
SCALE: NTS
DRAWN: JZ
SHEET. No.
REV.